

**CNC**<sup>4</sup>PC  
Integration Solutions for CNC Projects

**USER'S  
MANUAL  
VER. 1**

**C34KY-M BOARD  
Rev. 1**



FEBRARY, 2020

---

## USER'S MANUAL

### TABLE OF CONTENTS

Contents	<u>Page #</u>
<b>1.0 OVERVIEW.....</b>	<b>1</b>
<b>2.0 FEATURES.....</b>	<b>1</b>
<b>3.0 BOARD DESCRIPTION.....</b>	<b>2</b>
<b>4.0 JUMPER TO SELECT THE ENABLE.....</b>	<b>2</b>
<b>5.0 JUMPER TO SELECT THE DIFFERENTIAL.....</b>	<b>3</b>
<b>6.0 JUMPER TO SELECT ACTIVE LOW OR ACTIVE HIGH.....</b>	<b>3</b>
<b>7.0 ALARM TERMINAL.....</b>	<b>3</b>
<b>8.0 WIRING SAMPLE.....</b>	<b>4</b>
<b>8.1 Diagram of connection with input signals Step &amp; Dir and C76.....</b>	<b>4</b>
<b>8.2 Diagram of connection with input signals Differentials C74 and C76. ....</b>	<b>5</b>
<b>9.0 PINOUT.....</b>	<b>6</b>
<b>10.0 DIMENSION.....</b>	<b>7</b>

---


## 1.0 OVERVIEW

This board interface is used for the connection between [C82](#), [C76](#), [M16D](#), [C35S](#) y [C74](#) and YAKO Servo Driver M Series.

## 2.0 FEATURES

- HDM44D connector for Connection of Driver.
- RJ45 Connector for Axis.
- Encoder Output.
- Select Jumper for Hard Enable or Soft Enable.
- Select Jumper alarm active Low or active High
- Select jumper for signal differentials.
- Terminals for external drive enable push button.


### 3.0 BOARD DESCRIPTION




### 4.0 JUMPER TO SELECT THE ENABLE

Use Software Enable to keep the driver active only while the system is active. Set of jumpers as shown in the image.

SOFT ENABLE





HARD ENABLE



Use Hardware Enable to keep the driver enabled all the time. Set of jumpers as shown in the image.


## 5.0 JUMPER TO SELECT THE DIFFERENTIAL

If using Differential Signals, it is required to use the [C74](#) connector:




## 6.0 JUMPER TO SELECT ACTIVE LOW OR ACTIVE HIGH


1-2: ACTIVE HIGH



2-3: ACTIVE LOW




## 7.0 ALARM TERMINAL




## 8.0 WIRING SAMPLE

### 8.1 Diagram of connection with input signals Step & Dir and C76.



C34KY-M BOARD

## 8.2 Diagram of connection with input signals Differentials C74 and C76.



C34KY-M BOARD

---

## 9.0 PINOUT

YAKO DRIVE AND C34KY-M CONNECTION		
HDM44D PIN	FUNCTION	RJ45 PIN
4	STEP-	1
3	STEP+	2
6	DIR-	3
8	GND	4
12	SOFT_EN	5
9	ALARM	5
5	DIR+	6
	24VDC	7
13	5VDC	8

**Note:**


\* Servo ON and Alarm signals are related to the RJ45 pin 5 of the C34KY-M board, but they are not connected directly to this pin.

RJ45 for Encoder

HDM44D PIN	RJ45 PIN	FUNCTION
	1	GND
	2	NC
	3	NC
	4	NC
31	5	A-
16	6	A+
32	7	B-
18	8	B+



## 10.0 DIMENSION



All dimensions are in Millimeters.

## DISCLAIMER

Use caution. CNC machines can be dangerous machines. Neither DUNCAN USA, LLC nor Arturo Duncan are liable for any accidents resulting from the improper use of these devices. This product is not a fail-safe device and it should not be used in life support systems or in other devices where its failure or possible erratic operation could cause property damage, bodily injury or loss of life.