



# MULTIFUNCTION CNC BOARD SAMPLE WIRING DIAGRAM C11T REV1



- Grounding for the ERR/RES signal is required.
- If using multiple drivers, it is only necessary to wire this for one of the drivers only.
- Wiring this violates the optoisolation of the driver.